TROUBLESHOOTING:

	Possible Cause	Corrective Action
Bulb will not light	1. Bulb is burned out	1. Replace light bulb
	2. Switch is off	2. Make sure switch is on
	3. Faulty wire connection	3. Check wiring
Fuse blows or circuit breaker trips when light is turned on	Crossed wires or power wire is grounding out	Check wire connections

PRODUCT MAINTENANCE:

1. To clean the outside of the lamp, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the shade and surface of the lamp.

2. To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the inside shade and interior surface of the fixture.

3. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

LIMITED WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. **The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor expense costs involved in the replacement or repair of said product.**

INSTRUCTION MANUAL

INTERIOR 3-LIGHT SEMI-FLUSHMOUNT
ANGELINA

HOME DEPOT SKU 598-318 | S/O: 426-484 (UPC 773546217477)
RUSTIC FINISH



Thank you for purchasing this Hampton Bay interior decorative lighting. This product has been manufactured with the highest standards of safety and quality.

FEATURES:

This contemporary but classic semi-flushmount with a rustic finish complements any décor with its timeless look and style.

QUESTIONS, PROBLEMS, MISSING PARTS:

Before returning to your local Home Depot, please call our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your **SKU 598-318 or (UPC 773546217477).**

CAUTION:

1. Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

2. CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS.

3. If you have any non-electrical question about this fixture, please contact our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your **SKU 598-318 or (UPC 773546217477).**

4. Keep your receipt and these Instructions for Proof of Purchase.

INSTALLATION:



Figure #1



ADDITIONAL PARTS FOR INSTALLATION (included):



2. Cross Bar



3. Outlet Box Screw (x2)



4. Mounting Screw (x2)

6. Decorative Cap (x2)



7. Ground Screw

14. Wire Nut (x3)

INSTALLATION INSTRUCTIONS:

1. Turn off power at main fuse box.

2. Mount cross bar (2) onto junction box (1) with 2 outlet box screws (3) supplied.

3. Fasten open end of ground wire (bare copper or green wire), to ground wire or ground screw of junction box (1) or ground screw on cross bar (2). (See fig 1)

4. Connect black wire of power supply to black wire of the fixture and the white wire of the power supply to the white wire of the fixture. (See fig 1)

NOTE: All wire connections should be made with wire nuts (14) or marrettes (included) and pushed back into junction box (1).

5. Mount Canopy (5) of fixture over mounting cross bar (2) and secure with 2 decorative caps (6) supplied.

TOOLS REQUIRED FOR ASSEMBLY & INSTALLATION (not included):

Safety goggles

Wire Strippers



Wire Cutters



Flathead Screwdriver



Phillips Screwdriver



Electrical Tape

Ladder

A19 Bulb 60W max. (not included)

ADDITIONAL PARTS FOR ASSEMBLY (included):

10. Metal Washer

12. Diffuser

13. Decorative Finial

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack the fixture; Layout all parts on a clean surface.

2. Install A19 Bulb 60W max.(not included).

3. Attach fabric shade (8) to the bottom of nipple (9).

4. Install metal washer (10), washer (11), diffuser (12) and over bottom nipple (9) and secure them by fastening decorative finial (13) onto bottom nipple (9).

ASSEMBLY: